

Blue Ox Gooseneck Hitch Fit Applications

Year	Model	Bed Length	P/N	Notes
Chevy/GMC				
2011-2017	2500, 3500	6'-6" & 8'	DH2303	1,2
2007-2015	1500	5'-7", 6'-6"	DH2301	1
2007-2017	1500	5'-7", 6'-6"	DH2304	1
2001-2010	2500	6'-6" & 8'	DH2302	1
2007-2010	3500	6'-6" & 8'	DH2302	1,2,4
Ram (Dodge)				
2009-2017	1500 (No 4 Corner Air Suspension)	5'-7", 6'-4" & 8'	DH2100	1
2003-2012	2500, 3500	6'-4" & 8'	DH2101	1,2,3
2013	2500 (Includes Mega-Cab)	6'-4" & 8'	DH2101	1,2,3
2014-2017	2500	6'-4" & 8'	DH2102	
2006-2012	1500, 2500, 3500 Mega-Cab	6'-4"	DH2101	1,2,3
Ford				
2011-2016	F250, F350, F450 (Includes Super Duty)	6'-9" & 8'-2"	DH2200	1,2,5
2017	F250, F350 (Includes Super Duty)	6'-9" & 8'-2"	DH2204	1,2
2017	F450 (w/ Factory Installed Bed) (Includes Super Duty)	6'-9" & 8'-2"	DH2204	1,3
2004-2014	F150	5'-6", 6'-6" & 8'	DH2201	1
2015-2017	F150	5'-6", 6'-6" & 8'	DH2203	1,2
1999-2010	F250, F350, F450	6'-9" & 8'-2"	DH2202	1,2,3
Toyota				
2007-2017	Tundra	6'-6" & 8'	DH2400	1,3
Chassis Cab (All Makes w/ 34" Frame)				
n/a	Chassis Cab Frame (34")	n/a	DH2500	
Weld In Kit				
n/a	Flat Bed Applications (Minimum thickness 1/4")	n/a	DH9010	
5th Wheel Rail Adapter				
n/a	Standard 5th wheel rail spacing	n/a	DH9011	6

Gooseneck Hitch Footnotes:

1 = OEM Bed

2 = No Chassis Cab Models

3 = Exhaust Hangers provided to lower exhaust

4 = (1) Crossmember over Axle

5 = Hitches manufactured prior to 4/14/16 will not fit 2016 models with the factory brake re-location bracket

6 = Works only with Blue Ox Gooseneck Hitch with Quick Flip Ball