



BX3729 Installation Instructions 1995-97 Toyota Tacoma 2WD Pick-Up

Utilization of Blue Ox baseplates with any tow bar not approved by Automatic Equipment Mfg. Co. invalidates the limited warranty.

Installation of this baseplate requires removing the vehicle's tie down brackets.

1. Read the General Instruction Sheet included with this baseplate.
2. The baseplate mounts to the vehicle using four existing bolts.
3. Notice the tie-down brackets that attach to the frame rails on each side, directly behind the bumper. These are black, formed pieces of metal that bolt underneath the frame rails with two bolts apiece.
4. These brackets will be removed and the end pieces of the baseplate will bolt to the frame using the same two bolts. Begin by removing all four bolts with a 17mm socket. Set the tie-down brackets aside. They will not be reattached to the vehicle.
5. With an assistant, hold the baseplate underneath the frame rails and start the existing bolts through the baseplate slots and holes. Be sure to include Loctite on the bolt threads. When all four bolts are started, they may be tightened.
6. The dimensional variations between otherwise identical cars can be considerable. While the location and size of the holes in the baseplate were designed to allow for easy installation, it may be necessary to file a hole slightly to allow a bolt to clear.
7. Install the tow bar and safety cables according to the instructions included in their packages.
8. Do not substitute other devices if the tow bar pin and clip are lost.
9. DEALER OR INSTALLER: BE CERTAIN THE USER RECEIVES THE INSTRUCTION SHEET.

Tools Required

17mm Socket

Loctite Blue

Automatic

Parts List

Ref. No.	Qty.	Part No.	Description
1	1	61-4631	Weldment, Baseplate, BX3729
E	4	Existing Bolt

