



BRK2514 Patriot Brake Claw, FIAT Installation Instructions



Patriot Brake Claw Replacement for FIAT

BRK2514
Patriot Brake Claw, FIAT
Installation Instructions

1. Unscrew pre-installed brake claw from the actuator arm of the Patriot Braking System. Screw FIAT brake claw onto actuator arm.



2. Hold the lever back and slide the wire form underneath the pedal. Bring the claw up all the way onto the pedal until the bottom of the claw is resting against the front edge of the pedal. Slide the wire form as far up the underside of the pedal as it will go.
 3. Snap the lever forward to lock the claw onto the pedal. Fit should be tight and the claw should not move if grabbed.
4. Proceed with the normal tow brake setup and make sure the claw is still in position after the brake initializes.



Note: If the wire form gets stuck behind the metal stop located on the side of the claw, it will not work properly. Move the wire form back into position if this happens.

BRK2514
Patriot Brake Claw, FIAT
Installation Instructions

CUSTOMER SERVICE COMMITMENT

Blue Ox® is committed to providing you with exceptional customer care throughout your lifetime with our products. Our team is here to assist you with any questions you may have regarding the performance of your product. Simply call (402) 385-3051 and you can speak with our customer care team.

Additionally, please visit our website to see which rallies our Destination America team will be attending. For a nominal fee, our service technician will service your towing system to ensure it's in proper working condition. Also, as a commitment to our customers, should you visit our factory, you can stay at our full service Blue Ox® campground at no charge along with enjoying a factory tour.

Again, thank you for being our customer and for the confidence you have shown in the performance of our products. It is because of customers like you we enjoy the success we have today.



© 2013 Blue Ox
One Mill Road, Industrial Park
Pender, Nebraska 68047
Phone: (402) 385-3051
Fax: (402) 385-3360
www.blueox.com